

Sensor Description	Non-Discriminating Standalone Dispenser Pan Sensor	containment. When fluid is of the dispenser without the ne	ndalone Dispenser Pan Sensor is designed to detect liquid in a dispenser pan detected in the dispenser pan, this sensor shuts down (removes) AC power to eed for additional relays, circuitry, wiring, or an ATG System. The separate sures intrinsically-safe integrity in a Class 1 Div. 1 Group D; Class 1 Zone 0 IIA	
Part Number	847990-001			
Category	☐ Discriminating ☑ Non-Discriminating ☐ Position Sensitive	☐ Level Sensing☐ Static Testing☐ Hydrostatic		
Fuel Compatibility	✓ Gas ✓ E-15 ✓ Green Diesel ✓ Diesel ☐ E-85 ☐ DEF ✓ Kerosene ☐ E-100 ✓ Waste Oil ✓ Jet Fuel ✓ Bio-Diesel 20 ✓ Motor Oil ✓ Aviation Gas ☐ Bio-Diesel 100			
Console Compatibility	Not Required			
Alarm Notification	Normal	Dispenser operational		
	Liquid Detected Remove power to the dispense		ıser	
	Sensor Out	Remove power to the dispen	move power to the dispenser	
Installation Kit	330020-012 Universal Sensor Mounting Kit (Sold separately)			
Specifications			Example Installation	
Operating Principle	Reed switch/float			
Product Activation Height	Gasoline: 1.71" (4.34cm), water: 1.62" (4.11cm)			
Operating Temperature	+32 to +140°F (0 to +60°C) (freezing liquids)		Dispenser Control Interface	
Dimensions	11.6" (29.4cm) high, 2.2" (5.6cm) dia.		Neutral — To dispenser	
Miscellaneous/Notes	Latching alarm circuitry ensures dispenser can not be restarted until hazardous condition has been corrected. Connects directly to dispenser wiring. Controls most manufacturer's dispensers. Cable length: 5ft (1.5m). Control interface dimensions: 9.4" (23.9cm) high, 2.2" (5.6cm) dia.		Existing conduit 1-1/2" (3.81cm) to 3/4" (1.9cm) NPT Reducer 3/4" (1.9cm) NPT nipple (customer	
Third Party Evaluation Link	http://nwglde.org/evals/veeder_root_p.html		supplied)	
Product Link	Non-Discriminating Stand-Alone Dispenser Pan Sensor		Junction box (in dispenser)	
Warranty with System	1 Yr Parts & Labor			
Warranty (When purchased separately)	1 Yr Parts Only		*Dispenser pan sensor should: 1. Rest in the cup or the	
Where Used (Typical) ☑ Dispenser Pan		ell	lowest point of the dispenser pan. 2. Be positioned so as to be removable by pulling the sensor straight up out of the pan. 3. Be mounted in a true vertical position.	

Notice

Veeder-Root makes no warranty of any kind with regard to this publication, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose.

Veeder-Root shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this publication.

Veeder-Root reserves the right to change system options or features, or the information contained in this publication.

This publication contains proprietary information which is protected by copyright. All rights reserved. No part of this publication may be photocopied, reproduced, or translated to another language without the prior written consent of Veeder-Root.

Example Illustrations

Illustrations used in this guide for example sensor installations may contain components that are customer supplied and not included with the sensor. Please check with your Veeder-Root Distributor for recommended installation accessories.

Third Party Evaluations

Third party evaluations of the Veeder-Root sensors contained in this application guide can be found under the Veeder-Root vendor name on the National Work Group on Leak Detection Evaluations (NWGLDE) website:

http://www.nwglde.org