



INSTALLATION INSTRUCTIONS CAPACITOR CLIP KIT

Part No. 113-098-5


The following defined terms are used throughout Red Jacket literature, manuals and instructions to bring attention to the presence of hazards of various risk levels, or to important information concerning the life of the product.

DANGER indicates presence of a hazard which *will* cause *severe* personal injury, death or substantial property damage if ignored.

CAUTION indicates presence of a hazard which *will* or *can* cause *minor* personal injury or property damage if ignored.

WARNING indicates presence of a hazard which *can* cause *severe* personal injury, death or substantial property damage if ignored.

NOTICE indicates special instructions on installations, operation, or maintenance which are important but not related to personal injury hazards.



Step 1: **DANGER** Always disconnect and **LOCK** or **TAG OUT** the power before beginning any service to the pump.

Step 2: Remove capacitor cover.

Step 3: Remove old style capacitor retaining clip.

Step 4: Snap in new clip as shown above, positioning clip around casting lip beside the capacitor.

Step 5: Replace capacitor cover.



by **VEEDER-ROOT**

125 Powder Forest Drive • Simsbury, CT 06070
Tel: (860) 651-2700 • Fax: (860) 651-2719

041-927-1 Rev. E